


## Angle Framed Rectangle Mirror MODEL M1100,M1110,M1200,M1210

Installation Sheet
6201 S. Zero Street
Fort Smith, AR 72903
www.meekmirrors.com

**REVISION 10/2024** 



## **INSTALLATION:**

- 1) Disassemble the frame from back plate.
- 2) Mount back plate to wall using screw holes nearest the roll formed edge. Make sure the back plate is level and square.
- 3) Center mirror on back plate and hold in place. Make sure the mirror is firmly inside the frame.
- 4) Starting at the bottom of the frame, position and snap the frame over the roll formed flange. Continue up the sides and across the top.

Product made in the USA.

## Copyright 2024 Meek Mirrors LLC, All Rights Reserved.

All text, images and other materials contained or displayed here are proprietary and constitutes valuable intellectual property belonging to Meek Mirrors. No materials from any part of this document are authorized or intended by us to be reproduced or in any other way used or otherwise disseminated in any form to any person or entity, unless said person or entity has a license or authorization from us to do so. All unauthorized duplication or any other use of these materials shall constitute intentional infringement of our intellectual property and shall further constitute a violation of our trademark, copyright, and other rights.



